

APPENDIX A

The table below lists approved, Motorola Mobility, audio accessories that meet the requirements of the *France Acoustic Decree*. Match the group numbers indicated in the Declaration of Conformity for your device to determine the accessories it is approved to work with.

Group #	Connection Type	Kit #
1	2.5mm Mono	AAYN4264A
1	2.5mm Mono	AAYN4264C
1	2.5mm Stereo	CHYN4516B
1	2.5mm Stereo	SJYN0016A
1	2.5mm Stereo	SYN1308A
1	2.5mm Stereo	SYN1327A
1	2.5mm Stereo	SYN1461A
1	2.5mm Stereo	SYN1462A
1	2.5mm Stereo	SYN1462B
1	2.5mm Stereo	SYN1603B
1	2.5mm Mono	SYN1654A
1	2.5mm Stereo	SYN1922A
1	2.5mm Stereo	SYN2222A
1	2.5mm Stereo	SYN2223A
1	2.5mm Stereo	SYN2607A
1	2.5mm Stereo	SYN2664A
1	2.5mm Stereo	SYN2981A
1	2.5mm Mono	SYN8390B
1	2.5mm Mono	SYN8390C
1	2.5mm Mono	SYN8419C
2	3.5mm Stereo	CHYN4705A
2	3.5mm Stereo	SJYN0394A
2	3.5mm Stereo	SJYN0759A
2	3.5mm Stereo	SJYN0760A
2	3.5mm Stereo	SJYN0762A
2	3.5mm Stereo	SJYN0763A
2	3.5mm Stereo	SYN1302A
2	3.5mm Stereo	SYN1327B
2	3.5mm Stereo	SYN2356A
2	3.5mm Stereo	SYN2359A

2	3.5mm Stereo	SYN2567A
2	3.5mm Stereo	SYN2600A
2	3.5mm Stereo	SYN2601A
2	3.5mm Stereo	SYN2602A
2	3.5mm Stereo	SYN2603A
2	3.5mm Stereo	SYN2653A
2	3.5mm Stereo	SYN2663A
2	3.5mm Stereo	SYN2799A
3	Bluetooth	0171111F01
3	Bluetooth	CHYN4590A
3	Bluetooth	CHYN4590AB
3	Bluetooth	CHYN4590AC
3	Bluetooth	R61461014
3	Bluetooth	R61461015
3	Bluetooth	R61483014
3	Bluetooth	R61483016
3	Bluetooth	R61483024
3	Bluetooth	R61483026
3	Bluetooth	SPN5435A
3	Bluetooth	SPN5439A
3	Bluetooth	SPN5453A
3	Bluetooth	SPN5456A
3	Bluetooth	SPN5461A
3	Bluetooth	SPN5464A
3	Bluetooth	SPN5466A
3	Bluetooth	SYN0736A
3	Bluetooth	SYN0736B
3	Bluetooth	SYN0736C
3	Bluetooth	SYN0736E
3	Bluetooth	SYN0945A
3	Bluetooth	SYN0948A
3	Bluetooth	SYN0948B
3	Bluetooth	SYN0948C
3	Bluetooth	SYN0948D
3	Bluetooth	SYN0948E
3	Bluetooth	SYN0986A
3	Bluetooth	SYN1046A
3	Bluetooth	SYN1073B
3	Bluetooth	SYN1106A

3	Bluetooth	SYN1107A
3	Bluetooth	SYN1107B
3	Bluetooth	SYN1107C
3	Bluetooth	SYN1115A
3	Bluetooth	SYN1174A
3	Bluetooth	SYN1201A
3	Bluetooth	SYN1201B
3	Bluetooth	SYN1216A
3	Bluetooth	SYN1226A
3	Bluetooth	SYN1226B
3	Bluetooth	SYN1226C
3	Bluetooth	SYN1227A
3	Bluetooth	SYN1290A
3	Bluetooth	SYN1290B
3	Bluetooth	SYN1290C
3	Bluetooth	SYN1297A
3	Bluetooth	SYN1297B
3	Bluetooth	SYN1303B
3	Bluetooth	SYN1310A
3	Bluetooth	SYN1311A
3	Bluetooth	SYN1311B
3	Bluetooth	SYN1311C
3	Bluetooth	SYN1374A
3	Bluetooth	SYN1374B
3	Bluetooth	SYN1374C
3	Bluetooth	SYN1375A
3	Bluetooth	SYN1375B
3	Bluetooth	SYN1375C
3	Bluetooth	SYN1384A
3	Bluetooth	SYN1416A
3	Bluetooth	SYN1416B
3	Bluetooth	SYN1417A
3	Bluetooth	SYN1417B
3	Bluetooth	SYN1436A
3	Bluetooth	SYN1436B
3	Bluetooth	SYN1436C
3	Bluetooth	SYN1437A
3	Bluetooth	SYN1437B
3	Bluetooth	SYN1437C

3	Bluetooth	SYN1438A
3	Bluetooth	SYN1438B
3	Bluetooth	SYN1438C
3	Bluetooth	SYN1439A
3	Bluetooth	SYN1441A
3	Bluetooth	SYN1441B
3	Bluetooth	SYN1441C
3	Bluetooth	SYN1447A
3	Bluetooth	SYN1507A
3	Bluetooth	SYN1507C
3	Bluetooth	SYN1508B
3	Bluetooth	SYN1509B
3	Bluetooth	SYN1509C
3	Bluetooth	SYN1525A
3	Bluetooth	SYN1525B
3	Bluetooth	SYN1525C
3	Bluetooth	SYN1526A
3	Bluetooth	SYN1526B
3	Bluetooth	SYN1526C
3	Bluetooth	SYN1527A
3	Bluetooth	SYN1527B
3	Bluetooth	SYN1527C
3	Bluetooth	SYN1552A
3	Bluetooth	SYN1553A
3	Bluetooth	SYN1554A
3	Bluetooth	SYN1600A
3	Bluetooth	SYN1601A
3	Bluetooth	SYN1617A
3	Bluetooth	SYN1617B
3	Bluetooth	SYN1617C
3	Bluetooth	SYN1618A
3	Bluetooth	SYN1618B
3	Bluetooth	SYN1618C
3	Bluetooth	SYN1626A
3	Bluetooth	SYN1627A
3	Bluetooth	SYN1628A
3	Bluetooth	SYN1628B
3	Bluetooth	SYN1639A
3	Bluetooth	SYN1640A

3	Bluetooth	SYN1641A
3	Bluetooth	SYN1642A
3	Bluetooth	SYN1667A
3	Bluetooth	SYN1667C
3	Bluetooth	SYN1668A
3	Bluetooth	SYN1668B
3	Bluetooth	SYN1671A
3	Bluetooth	SYN1671C
3	Bluetooth	SYN1673A
3	Bluetooth	SYN1685A
3	Bluetooth	SYN1685C
3	Bluetooth	SYN1712A
3	Bluetooth	SYN1713A
3	Bluetooth	SYN1732A
3	Bluetooth	SYN1732C
3	Bluetooth	SYN1733A
3	Bluetooth	SYN1733C
3	Bluetooth	SYN1734A
3	Bluetooth	SYN1734C
3	Bluetooth	SYN1735A
3	Bluetooth	SYN1735C
3	Bluetooth	SYN1736A
3	Bluetooth	SYN1736C
3	Bluetooth	SYN1738A
3	Bluetooth	SYN1763A
3	Bluetooth	SYN1764A
3	Bluetooth	SYN1765A
3	Bluetooth	SYN1769B
3	Bluetooth	SYN1818B
3	Bluetooth	SYN1818C
3	Bluetooth	SYN1820B
3	Bluetooth	SYN1820C
3	Bluetooth	SYN1821A
3	Bluetooth	SYN1821B
3	Bluetooth	SYN1822A
3	Bluetooth	SYN1822B
3	Bluetooth	SYN1823A
3	Bluetooth	SYN1826A
3	Bluetooth	SYN1827A

3	Bluetooth	SYN1837C
3	Bluetooth	SYN1838C
3	Bluetooth	SYN1841A
3	Bluetooth	SYN1842A
3	Bluetooth	SYN1843A
3	Bluetooth	SYN1844A
3	Bluetooth	SYN1852A
3	Bluetooth	SYN1852B
3	Bluetooth	SYN1853A
3	Bluetooth	SYN1853B
3	Bluetooth	SYN1854A
3	Bluetooth	SYN1854B
3	Bluetooth	SYN1855A
3	Bluetooth	SYN1855B
3	Bluetooth	SYN1902A
3	Bluetooth	SYN1902B
3	Bluetooth	SYN1948A
3	Bluetooth	SYN1949A
3	Bluetooth	SYN1949B
3	Bluetooth	SYN1965A
3	Bluetooth	SYN1966C
3	Bluetooth	SYN1967A
3	Bluetooth	SYN1970A
3	Bluetooth	SYN1970B
3	Bluetooth	SYN1971A
3	Bluetooth	SYN1971B
3	Bluetooth	SYN2007C
3	Bluetooth	SYN2008C
3	Bluetooth	SYN2021A
3	Bluetooth	SYN2021B
3	Bluetooth	SYN2035A
3	Bluetooth	SYN2035B
3	Bluetooth	SYN2082B
3	Bluetooth	SYN2083A
3	Bluetooth	SYN2084B
3	Bluetooth	SYN2109B
3	Bluetooth	SYN2137A
3	Bluetooth	SYN2137B
3	Bluetooth	SYN2156A

3	Bluetooth	SYN2162A
3	Bluetooth	SYN2168A
3	Bluetooth	SYN2168B
3	Bluetooth	SYN2172B
3	Bluetooth	SYN2208B
3	Bluetooth	SYN2209B
3	Bluetooth	SYN2235A
3	Bluetooth	SYN2253A
3	Bluetooth	SYN2255A
3	Bluetooth	SYN2257A
3	Bluetooth	SYN2257B
3	Bluetooth	SYN2259A
3	Bluetooth	SYN2305A
3	Bluetooth	SYN2305B
3	Bluetooth	SYN2324A
3	Bluetooth	SYN2324B
3	Bluetooth	SYN2339A
3	Bluetooth	SYN2340A
3	Bluetooth	SYN2341A
3	Bluetooth	SYN2347A
3	Bluetooth	SYN2351A
3	Bluetooth	SYN2352A
3	Bluetooth	SYN2386A
3	Bluetooth	SYN2397A
3	Bluetooth	SYN2397B
3	Bluetooth	SYN2409A
3	Bluetooth	SYN2410A
3	Bluetooth	SYN2434A
3	Bluetooth	SYN2434B
3	Bluetooth	SYN2463B
3	Bluetooth	SYN2465B
3	Bluetooth	SYN2468A
3	Bluetooth	SYN2487A
3	Bluetooth	SYN2487B
3	Bluetooth	SYN2492A
3	Bluetooth	SYN2506A
3	Bluetooth	SYN2516A
3	Bluetooth	SYN2516B
3	Bluetooth	SYN2517A

3	Bluetooth	SYN2518A
3	Bluetooth	SYN2527A
3	Bluetooth	SYN2561A
3	Bluetooth	SYN2576A
3	Bluetooth	SYN2584A
3	Bluetooth	SYN2585A
3	Bluetooth	SYN2609A
3	Bluetooth	SYN2614A
3	Bluetooth	SYN2615A
3	Bluetooth	SYN2618A
3	Bluetooth	SYN2619A
3	Bluetooth	SYN2625A
3	Bluetooth	SYN2626A
3	Bluetooth	SYN2627A
3	Bluetooth	SYN2631A
3	Bluetooth	SYN2644A
3	Bluetooth	SYN2645A
3	Bluetooth	SYN2646A
3	Bluetooth	SYN2647A
3	Bluetooth	SYN2694A
3	Bluetooth	SYN2695A
3	Bluetooth	SYN2707A
3	Bluetooth	SYN2708A
3	Bluetooth	SYN2722A
3	Bluetooth	SYN2729A
3	Bluetooth	SYN2801A
3	Bluetooth	SYN2804A
3	Bluetooth	SYN2805A
3	Bluetooth	SYN2806A
3	Bluetooth	SYN2874A
3	Bluetooth	SYN2879A
3	Bluetooth	SYN2901A
3	Bluetooth	SYN2967A
3	Bluetooth	SYN2979A
3	Bluetooth	SYN2983A
3	Bluetooth	SYN3001A
3	Bluetooth	SYN3002A
3	Bluetooth	SYN3060A
3	Bluetooth	SYN3115A

3	Bluetooth	SYN3117A
3	Bluetooth	SYN3118A
3	Bluetooth	SYN9951A
4	EMU Stereo	CHYN4704B
4	EMU Mono	SYN0896C
4	EMU Stereo	SYN1301B
4	EMU Stereo	SYN1457A
4	EMU Stereo	SYN1457B
4	EMU Mono	SYN1471A
4	EMU Mono	SYN1471B
4	EMU Mono	SYN1504B
4	EMU Stereo	SYN1562A
4	EMU Stereo	SYN1632A
4	EMU Stereo	SYN1709A
4	EMU Stereo	SYN1744A
4	EMU Stereo	SYN1867A
5	Micro USB Stereo	SYN1458A
5	Micro USB Stereo	SYN1458B
5	Micro USB Mono	SYN1472A
5	Micro USB Mono	SYN1472B
5	Micro USB Stereo	SYN2357A
5	Micro USB Stereo	SYN2466A
5	Micro USB Stereo	SYN2809A
5	Micro USB Stereo	SYN2991A